

Tire Spreaders

Separadores de llantas • Écarte-pneus

Tire Spreader with Lock Pin

Separador de llanta con pasador de bloqueo

Écarte-pneu avec goupille de sécurité



Model	EDP No.	Spread Capacity	Weight
T51	31551	4" - 6" (10-15 cm)	3.9 lbs (1.7 kg)

Tire Spreader

Separador de llanta

Écarte-pneu



Model	EDP No.	Spread Capacity	Weight
T53	31553	7-1/2" (19 cm)	3 lbs (1.4 kg)

Ratchet Action Truck Tire Spreader

Separador de llantas para camiones

Ratchet Action

Écarte-pneu à rochet pour camions



Model	EDP No.	Spread Capacity	Weight
T54	31554	3-1/2" - 14" (9 - 36 cm)	7.3 lbs (3.3 kg)

Wire Brush

Cepillo de alambre • Brosse métallique



Cleans rust from rims

Model	EDP No.	Length	Weight
T15	30515	14" (36 cm)	5 oz. (.2 kg)

"Challenger" Wheel Balancer

Balanceador de ruedas • Équilibreuse de roues

Accurate, easy-to-operate, self-leveling balancer with easy-to-read circular level accurately balances all wheels when using regular weights. Bubble type balancer is portable and may be used indoors or outdoors, even on a stone driveway. Convenient built-in weight storage space in the base of the balancer combines everything needed in 2 sq. ft. of floor space. All steel parts are plated to resist rust. Most passenger car wheels can be balanced directly on the balancer. Bubble will not freeze. Restriction: Minimum 1-1/2" diameter hub holes to maximum 4-1/2" hub holes.



Model	EDP No.	Description	Size	Weight
B260	31360	Wheel Balancer	22"H x 12"W x 12"L	14 lbs (6.4 kg)
B261	31360-01	Balance Head		5.3 lbs (2.4 kg)
B262	31360-99	Bubble Device		.75 lbs (.3 kg)

Wheel Tools

Herramientas para ruedas • Outils pour roues

Wheel Weight Pliers

Alicates para pesar ruedas • Pinces de masse d'équilibrage



These rugged pliers are designed to grip wheel weights firmly, with or without a hole in the clip, and to remove them quickly and easily. Balanced hammer head drives clips into place with a few light blows. The end of the handle is offset and flat to remove wheel covers. Finished in a bright luster plate.

Model No.	EDP No.	Jaw Style	Length	Weight
7220	7220	Straight	10" (25.4 cm)	.97 lbs (.44 kg)
7221	7221	Angle	10" (25.4 cm)	1 lb (.5 kg)

Heavy-Duty Wheel Weight Pliers

Alicates para pesar ruedas de alta resistencia

Pinces de masse d'équilibrage robustes



These rugged truck-style wheel weight pliers are designed for heavy-duty use. They will grip wheel weights firmly, with or without a hole in the clip, and remove them quickly and easily. The extra large, perfectly balanced hammer head drives clips into place with a few light blows. The angle jaw style allows you to install weights on the back side of the wheel, as well as the front side. Finished in a bright luster plate.

Model No.	EDP No.	Jaw Style	Length	Weight
7218	7218	Straight	10" (25.4 cm)	1.5 lbs (.68 kg)
7219	7219	Angle	10" (25.4 cm)	1.5 lbs (.68 kg)

Grease Cap Remover

Desmontador de engrasador

Dégazeur de chapeau



Makes a messy, time consuming job easy. The thin jaws of these powerful pliers slip behind the grease cap, and the wedge shape of the jaws forces the cap away from the hub. The end of the handle has been machined for the quick removal of wheel covers. The finish is bright luster plate.

Model No.	EDP No.	Length	Weight
7223	7223	11-1/2" (29.2 cm)	1.1 lbs (.5 kg)

Professional Wheel Weight Tool

Herramientas profesional para pesar ruedas

Outil professionnel pour masses d'équilibrage

Clip-claw crowbar, punch designed handles, and heavy hammerhead provide years of use.



Model	EDP No.	Weight
B230	35354	1 lb (.5 kg)

Standard Wheel Weight Tool

Herramientas estándar para pesar ruedas

Outil standard pour masses d'équilibrage

This passenger car wheel weight tool is the industry standard.



Model	EDP No.	Weight
B232	35355	1 lb (.5 kg)