

Commercial-Duty Wrench Support Stand

Use to support double-end truck wrench
or 4-way lug wrench when removing
or replacing lug nuts

Warning:

This tool is to be used as a lug nut wrench support **only**.
Do not use when any components are damaged.
Maximum load/torque 300lbs.

Instructions:

Put wrench on lug nut.
Raise support to wrench height so wrench is cradled in the stand.
Position wrench/leverage bar at horizontal angle with ground
Push down on one side of the wrench/leverage bar to break the lug nut loose or
to tighten the lug nut.
Continue with the same process until all lug nuts have been loosened or
tightened.

Patent Pending