Ken-Tool®

WHEREVER TIRES ARE CHANGED™

TIRE BEAD SEATERS



ONE-PIECE RUBBER TUBE FOR MOUNTING HARD-TO-SEAT RADIAL, BIAS-BELTED, OR CONVENTIONAL TRUCK TIRES!

As tire is inflated, the lubricated bead seater forms a seal between the rim and tire, allowing the air pressure to force the beads into the rim flange. As proper pressure is reached, the bead seater slides out and over the rim. Use bead lubricant with bead seaters.

PASSENGER/LIGHT TRUCK BEAD SEATER PN 31446
Fits Rim Sizes: 14-15" (36 - 38 cm) Weight: 1.5 lbs (.7 kg)

TRUCK BEAD SEATER PN 31437
Fits Rim Sizes: 16-1/2" to 17-1/2" (42 to 45 cm) Weight: 2 lbs (.9 kg)

TRUCK BEAD SEATER PN 31438
Fits Rim Sizes: 19-1/2" (50 cm) Weight: 2.3 lbs (1 kg)

TRUCK BEAD SEATER PN 31439
Fits Rim Sizes: 22-1/2" to 24-1/2" (57 to 62 cm) Weight: 2.3 lbs (1 kg)

www.KENTOOL.com

1-888-536-8665

768 E. North Street, P.O. Box 9320 | Akron, Ohio 44305 | 330-535-7177 | sales@kentool.com | © 2025 Ken-Tool. All Rights Reserved. KT20250602